

### Content

① 1x Electronic Paper Display

1 x Fastener Kit containing:

② Metal clips (x2)

③ Screw + nut (x2)

④ Tesa Powerstrips® (x2)



**SCAN QR-CODE FOR HOW-TO-SET PRICING & NIGHT SLEEP**

<https://www.motiondisplay.com/gallo-price-2025/>

### Display Control Buttons

Animation On/Off



⤴ ≥2 seconds

Enter/Exit Setting Mode\*



⤴ ≥2 seconds

Set Values (in Setting Mode)



⤴ Change position  
⤵ Change value \*\*

**Note!** Long press on both buttons simultaneously for **Night Sleep Setting**.

### Setting Mode Overview



Position - Change position with button ⤴



Setting Mode is indicated by a black background.  
Currently selected position is flashing.

Each digit is set individually.

If leading digit is set to blank (don't show), a short flash indicates current position.

If price value is set to 0 (blank, 0,0,0) it will not be included in animation.

\* 20s idle will exit Setting Mode \*\* Changed values take effect immediately

### Night Sleep Activation

The battery life length can be extended by activating the Night Sleep mode, and the display will sleep for 8 hours per day. During Night Sleep, the animation stops and the current price is shown together with a small moon symbol. If the price is set to 0, a predetermined Night Sleep message is shown instead.



#### Activate Night Sleep




Long press on both buttons simultaneously moves into **Night Sleep Setting**, first time with **12** blinking, indicating that Night Sleep (NS) has now been activated and that 12 hours remain until the display will go to sleep.



To change the number of hours before the display goes to sleep, push until the requested numbers of hours before going to sleep (0-15) is displayed.

#### To turn OFF NS:

1) push to make only **h** blinking, then



then 2) push , and the OFF screen is shown, indicating that NS has been turned off.



Pushing repeatedly toggles between "OFF" and "h xx".

Holding down for a long time exits NS setting—or just wait for "time-out".

#### Check number of hours to Night Sleep (for Night Sleep activated display)

Move into NS Setting with a long press on both buttons simultaneously.

Display now tells how many hours left until NS. Example: If initial setting was "h 12" and two hours have past, the display will now show "h 10").

By changing value (1-15) with , the new selection will be activated.

Holding down for a long time exits NS setting - or just wait for "time-out".

Note! Moving into NS setting always activates Night Sleep.

If the display is sleeping, (*the moon symbol is visible*), moving into NS activates the display for one animation sequence, enough time to activate NS setting and chose a new time or turn "OFF" NS.




### Replacing the Batteries

When it is time to replace the batteries, a battery symbol is shown and the display stops animating, showing the current price, the so called End of Life view.



Squeeze the "snap locks" and slide the extrusion off the display to expose the batteries. Remove and replace the batteries, the "+" sign facing up. Slide the display back according to image until locked in position.

*Do not mix old batteries with new ones. Only use CR2450 batteries!*



#### LEGAL DISCLAIMER:

MOTION DISPLAY SCANDINAVIA AB AND ALL ITS AFFILIATES DISCLAIM ANY AND ALL RESPONSIBILITY FOR USE OF MOTION DISPLAY PRODUCTS FOR OTHER PURPOSES THAN ITS INTENDED USE AS DESCRIBED IN THIS USER INSTRUCTION. INSTALLATION AND REMOVAL MAY ONLY BE PERFORMED BY AUTHORIZED PERSONNEL, AND SHALL BE MADE ONLY IN ACCORDANCE WITH THIS INSTRUCTION. MOTION DISPLAY DISCLAIM ALL RESPONSIBILITY FOR ANY INJURIES CAUSED BY WRONGFUL HANDLING OF THE PRODUCT, INCLUDING FROM ANY MATERIAL LEFT ON SHELF AFTER REMOVAL.